


SADDLE BAG PATTERN PAK

STOCK NO. 1917



YOU WILL NEED:

7/8 oz. Leather
Buckles
Latigo Lacing
Rivets

Nos. 3 & 5 Round Drive Punches
Super Shears
Latigo Life-Eye Needle
Tools, Dyes and Finishes for Design

tandy Est. 1919
LEATHER COMPANY

SADDLE BAG PATTERN A & B

STOCK NO. 1917


FOR BAG (A) YOU WILL NEED:

12½ sq. ft. of 7-8 oz. Leather
10 ft. Latigo Lace
14 Long Rapid Rivets
4 Medium Rapid Rivets
2 Buckles $\frac{3}{4}$ "
No. 5 Drive Punch
No. 3 Drive Punch
Heavy Brown Paper or Tracing Film
Super Shears
Latigo Life-Eye Needle
Tools, Dyes and Finishes for Design


FOR BAG (B) YOU WILL NEED:

9 sq. ft. of 7-8 oz. Leather
9 ft. Latigo Lace
10 Long Rapid Rivets
4 Medium Rapid Rivets
2 Buckles $\frac{3}{4}$ "
No. 5 Drive Punch
No. 3 Drive Punch
Heavy Brown Paper or Tracing Film
Super Shears
Latigo Life-Eye Needle
Tools, Dyes and Finishes for Design






STEP 1. Trace patterns from pattern sheet on to brown paper or tracing film. Be sure to mark all holes and directions indicated on pattern sheet. Cut out your patterns.



STEP 2. Trace your patterns onto leather, marking all holes and following directions on pattern sheet.




STEP 3. Punch holes as indicated on pattern sheet.

DO ALL CARVING, TOOLING, DYEING AND FINISHING BEFORE GOING ON TO NEXT STEP!




STEP 4. Fold Buckle Tab through buckle, inserting buckle tongue in slot.




STEP 5. Insert ends of Buckle Tab through slit in Bag Front, from grain side, and align holes in ends of tab with hole below slit in Bag Front.


STEP 6. Using a medium rivet, push post of rivet through holes in tab and then through hole in Bag Front. Place assembly on metal riveting surface. Place rivet cap over rivet post on grain side of Bag Front. With concave face of rivet setter on cap of rivet, strike setter sharply with a mallet. Repeat Steps 4 through 6 on other Bag Front.




STEP 7. Insert square end of Closing Strap through slit in Bag Flap, from grain side, and align top hole in Closing Strap with hole above slit in Bag Flap. Set rivet in holes as in Step 6. Repeat on other Bag Flap.




STEP 8. Using 4' (3½' for Bag B) of latigo lace, push lace through second from top hole in Gusset from flesh side, leaving about 1/2" tail of lace in hole. Align holes in Gusset with holes around Bag Back, flesh sides together.




STEP 9. Push lace through first hole in both pieces of leather. Making sure that the grain side of the lace is on the grain side of the Gusset, push lace through second hole in both pieces of leather and pull tight.




STEP 10. Continue lacing in and out in a running stitch around the Bag Back and Gusset. When you reach the last hole, push lace back down through next to last hole in Bag Back only. Pull lace through to the inside of the bag and trim off excess lace.






STEP 11. Align holes in Bag Front with holes in other side of Gusset, flesh sides together, and stitch together as in Steps 8 through 10, except keep the grain side of the lace to the grain side of Bag Front. Repeat Steps 8 through 11 on other bag.




STEP 12. Align holes in Bag Flap with holes in bottom of Side Panel, grain sides together. Align holes in top of Bag Back over holes in Side Panel, flesh sides up. Set seven long rivets in holes with caps on Bag Back as in Step 6. Repeat on other bag.



STEP 13. Align holes in Joining Piece over holes in top of Side Panel and stitch together using 1' of lace. Repeat on other end of Joining Piece and other bag.

SADDLE BAG PATTERN C


STOCK NO. 1917




FOR BAG (C) YOU
WILL NEED:

FOR BAG (C) YOU
WILL NEED:


12 sq. ft. of 7-8 oz. Leather
20 ft. Latigo Lace
18 Medium Rivets
2 Buckles $\frac{3}{4}$ '
No. 5 Drive Punch
No. 3 Drive Punch
Heavy Brown Paper or Tracing Film
Super Shears
Latigo Life-Eye Needle
Tools, Dyes and Finishes for Design



STEP 1. Trace patterns from pattern sheet on to brown paper or tracing film. Be sure to mark all holes and directions indicated on pattern sheet. Cut out patterns.



STEP 2. Trace your patterns onto leather, marking all holes and following directions on pattern sheet.



STEP 3. Punch holes as indicated on pattern sheet.

DO ALL CARVING, TOOLING, DYEING AND FINISHING BEFORE GOING ON TO NEXT STEP!



STEP 4. Fold Buckle Tab through buckle, inserting buckle tongue in slot.



STEP 5. Insert ends of Buckle Tab through slit in Bag Front, from grain side, and align holes in ends of tab with hole below slit in Bag Front.


STEP 6. Using a medium rivet, push post of rivet through holes in tab and then through hole in Bag Front. Place assembly on metal riveting surface. Place rivet cap over rivet post on grain side of Bag Front. With concave face of rivet setter on cap of rivet, strike setter sharply with a mallet. Repeat Steps 4 through 6 on other Bag Front.




STEP 7. Insert square end of Closing Strap through slit in Bag Flap, from grain side, and align top hole in Closing Strap with hole above slit in Bag Flap. Set rivet in holes as in Step 6. Repeat on other Bag Flap.




STEP 8. Using 1 yd. of latigo lace, push lace through second from top hole in short side of Gusset from flesh side, leaving about 1/2" tail of lace in hole. Align holes in Gusset with holes in Bag Front, flesh sides together.




STEP 9. Push lace through first hole in both pieces of leather. Making sure the grain side of the lace is on the grain side of the Bag Front, push lace through second hole in both pieces of leather and pull tight.




STEP 10. Continue lacing in and out in a running stitch around the Gusset and Bag Body. When you reach the third to last hole, push lace back down through fourth to last hole in Gusset only. Pull lace through to the inside of the bag and trim off excess lace. Repeat Steps 8 through 10 on other end of bag.







STEP 11. Align holes in Bag Flap with holes in bottom of Side Panel, grain sides together. Set seven medium rivets in holes with caps on Side Panel as in Step 6.





STEP 12. Using 1yd. of lace, begin stitching in next to last hole in Gusset and stitch around Bag Flap following procedures in Steps 8 through 10. Repeat Steps 8 through 12 on other bag.




STEP 13. Align holes in Joining Piece over holes in top of Side Panel and stitch together using 1' of lace. Repeat on other end of Joining Piece and other bag.













748

P213 U855 H908 C454 B971 A888


| P714








BAG (A) JO
CU




BAG (A) SIDE PANEL
CUT 1 THEN FLOP
PATTERN AND CUT
1 MORE




○ BAG (A)

INING PIECE
T 1



BAG (A) BUCKLE STRAP
CUT 2




CLOSING STRAP
CUT 2




BAG (A) BACK
CUT 2

No. 5 Drive Punch



BAG (A) FRO
CUT 2






No. 5 Drive Punch





NT





No. 3 Drive Punch


© Copyright






2010 by Tandy Leather Factory
All Rights Reserved










STOCK NO. 1917 BAG (A)



FOR ALTERNATE STAMPING PATTERN
USE THESE STAMPS AROUND EDGES
OF BAG FRONT, BAG BACK, BAG FLAP
SIDE PANEL AND JOINING PIECE










C454 P704 B702


P213









○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○





FOR ALL
USE THE
OF BACK
SIDES





TERNATE STAMPING PATTERN
THESE STAMPS AROUND EDGES
FRONT, BAG BACK, BAG FLAP
PANEL AND JOINING PIECE





○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○



© Copyright 2010 by Tandy Leather Factory
All Rights Reserved

B,







No. 5 Drive Punch ✓

AG (A) GUSSET
CUT 2




0 0 0 0 0 0 0 0 0 0 0 0




STOCK NO. 1917 BAG (A)






BAG (B) CLOSING STRAP
CUT 2







B701 P714 S706


C

O

No. 3 Drive Punch ↗




BAG (B) BUCKLE STRAP
CUT 2




BAG (B) SIDE PANEL
CUT 1 THEN FLOP
PATTERN AND CUT
1 MORE






BAG (B) FLAP
CUT 2

No. 3 Drive Punch





© Copyright 2010 by Tandy Leather Factory
All Rights Reserved



BA(










No. 5 Drive Punch

G (B) GUSSET
CUT 2






STOCK NO. 1917 BAG (B)



FOR ALTERNATE STAMPING PATTERN
USE THESE STAMPS AROUND EDGES
OF BAG FRONT, BAG BACK, BAG FLAP
SIDE PANEL AND JOINING PIECE



○ ○

○

○

○

○

○

○

○

○

○

○

○

○



No. 3 Drive Punch




No. 5 Drive Punch




BAG (B) BACK
CUT 2



No. 5 Drive Punch






BAG (B) JOINING PIECE
CUT 1


B971



P213




'01

714











A888 P714 B702 C453


B971









© Copyright 2010 by Tandy Leather Factory
All Rights Reserved








FOR ALTERNATE STAMPING PATTERN
USE THESE STAMPS AROUND EDGES
OF BAG FRONT, BAG BACK, BAG FLAP
SIDE PANEL AND JOINING PIECE

D438 D436







STOCK NO. 1917 BAG (B)





BAG (C) SIDE PANEL
CUT 1 THEN FLOP
PATTERN AND CUT
1 MORE


© Copyright 2010 by Tandy Leather Factory
All Rights Reserved




FOR ALTERNATE STAMPING PATTERN
USE THESE STAMPS AROUND EDGES
OF BAG FRONT, BAG BACK, BAG FLAP,
SIDE PANEL AND JOINING PIECE




















FOR ALTERNAT
USE THESE STA
OF BAG FRONT
SIDE PANEL




THE STAMPING PATTERN
RAMPS AROUND EDGES
, BAG BACK, BAG FLAP
AND JOINING PIECE

P213 V748 C454 P714





5105

8884






BAG (C) SIDE I
CUT 1 THEN I
PATTERN AND
1 MORE





PANEL
FLOP
CUT

© Copyright 2010 by Tandy Leather Factory
All Rights Reserved








D438 D436








STOCK NO. 1917 BAG (C)























Gouge These Lines for Bottom Fold

No. 5 Drive Punch





BAG (C) JOINING PIECE
CUT 1



P213



U855

H908

C454

© Copyright 2010 by Tandy Leather Factory
All Rights Reserved

BAG
CUT
PA
L



G (C) GUSSET
IT TWO, FLOP
TTERN & CUT
TWO MORE.



No. 3 Drive punch



BAG (C) CLOSING STRAP
CUT 2

STOCK NO. 1917 BAG (C)