



From Tony Laier's Bench:

GEOMETRIC BORDER USING 69008-00, D436 & B893



You will need 69008-00, D436, B893 stamps, straight edge, stylus and a modeling tool.

- A) To stamp the border, first make light guidelines on your cased leather. Use a straight edge and stylus. For above design, scribe #1 guideline at desired distance from edge of project.
- B) Scribe #2 guideline 1/8" from first.
- C) Measure across face of geometric stamp (69008-00). Using that measurement, scribe #3 guideline.
- D) Scribe a 4th guideline 1/8" from 3rd line.
- E) Shape outside borders with modeling tool. Add texture by dragging B893 along the borders.
- F) Begin stamping with 69008-00. Overlap tips of stamp. Use guidelines to keep design straight.
- G) Add D436 as shown. Align stamp along guideline.

