


TRUCKER'S WALLET




—POCKET ASSEMBLY INSTRUCTIONS—

- 1 Assembly "A" Sew zipper to one of the inside pocket pieces, and to the carved pocket front, as shown at right. Both pieces grain side up.



- 2 Place 2nd inside pocket piece on first and sew together (see pattern position of sewing line). Rivet stress points indicated by stars.

- 3 Assembly "B": Take the two remaining pocket pieces, place them grain sides together and sew and rivet them together (at "stars")... as a separate unit (see below).



4

Place assembly "B" on assembly "A" and sew ground outer edges. Top and bottom pocket edges will have to be folded back to permit sewing (see exploded view above). After sewing, rivet corners. Install eyelet for chain, in the two inside pocket leathers only. See pattern for location.


—ASSEMBLY CONTINUED ON OPPOSITE SIDE—

TRUCKERS-WALLET KIT:

... designed for the man on the go! Help keep papers, currency and important documents safe, separate, but readily accessible. Heavy safety chain attached to belt, helps prevent loss. Genuine, top quality carving cowhide affords years of rigorous use and lasting beauty.

CUT FOUR PIECES
FOR INSIDE POCKETS
FROM 1½ oz. LEATHER

CUT ONE PIECE
FOR OUTSIDE POCKET
FROM 3-4 oz. COWHIDE



TRUCKER'S WALLET

ASSEMBLY INSTRUCTIONS

(CONTINUED)

- 5** Pocket assembly should look like illustration at right...now ready for final assembly.

- 6** Install snaps, and punch lacing holes in front and back pieces (see patterns)





- 7** Apply rubber cement to edges of flesh sides of zippered pocket...at arrows.

- 8** Fold and stick edges to-gether. Re-punch through holes to make holes in inside pocket piece.

- 9** Lay pocket and front piece assembly on back piece, Mark top of pockets. Cement edges on flesh sides; stick together. Repunch holes through back piece into inside pocket... same as procedure in step 8.


- 10** Now the project can be completely laced: use 1/8" lacing: double loop stitch.

- 11** Spread eye on chain hook and insert in eyelet. Re-clamp with pliers.



1/2 PATTERN

1/2 PATTERN



TRUCKER'S WALLET CONTINUED

USE SINGLE PRONG PUNCH AT CORNERS

USE A FOUR PRONG $\frac{1}{8}$ " LACING CHISEL, IF LACING SLITS ARE DESIRED.

CRAFT TOOL SPACER

No. 6 WHEEL

IF ROUND LACING HOLES ARE DESIRED, USE No. 6 SPACING WHEEL TO MARK; USE No. 0 PUNCH.

No. 0 PUNCH

POSITION OF DOT FASTENER BUTTON & SOCKET.

SET SNAPS WITH 7057 DURABLE DOT SETTER

SOCKET

BUTTON

ANVIL

**BACK
PIECE**

CUT FROM
 $\frac{4}{5}$ oz.
COWHIDE


$\frac{1}{2}$ PATTERN \longleftrightarrow $\frac{1}{2}$ PATTERN

GUIDE LINE FOR LACING HOLES



EDGE AND
BURNISH
EDGES

BELT LOOP
CUT FROM 3-4 oz. COWHIDE



FOLD STRAP AND
FASTEN TOGETHER
WITH EYELET

SPREAD EYE
IN CHAIN
HOOK AND
INSERT IN
EYELET. RE-
CLAMP WITH
PLIERS.




1/2 PATTERN
REVERSE PATTERN TO
COMPLETE DESIGN
FOR OPPOSITE SIDE

1/2 PATTERN
REVERSE PATTERN TO
COMPLETE DESIGN
FOR OPPOSITE SIDE




Digital Downloads

This PDF package has been put together to give you options when it comes to printing. Some PDF file downloads may contain some documents larger than an 8-1/2" x 11" image. Pages and patterns that are larger than 8½x11 have been provided in two formats:



Full Size: If you would like to have a full size print out, take the full size pages to your local print shop and they can print it for you.

Tiled: The tiled pages give you the option of printing the larger patterns at home. You print the tiled pages and then assemble them to make the larger patterns.



Pattern PDF files are typically laid out as follows: Cover (if applicable), instructions sheets (if applicable), pattern 1 – full sized, pattern 1 – tiled, pattern 2 – full sized, pattern 2 – tiled, pattern 3 – full sized, pattern 3 – tiled. ...Etc.


Doodle Page PDF files are typically laid out as follows: Front – full sized, front – tiled, back – full sized, back – tiled (Some Doodle Pages do not have backs).

eBook PDF files contain 1 (one) full eBook. All pages in the PDF are full sized. This means that you may have to take the PDF to a print shop for certain oversized books if your home printer cannot print the larger pages.

Craftaid PDF files contain 1 (one) full Craftaid pattern or Craftaid pattern pack that has been converted into a tracing pattern. All pages in the PDF are full sized. This means that you may have to take the PDF to a print shop for certain oversized Craftaid patterns if your home printer cannot print the larger pages. **NOTE: These digitized patterns do not include any of the physical plastic templates (Craftaids) that may be mentioned, nor does the purchase of this PDF file imply a promise to receive any physical plastic templates (Craftaids).**

NOTE: Digital kit patterns do not include any kit parts that they may reference.

Please note: When printing on a home printer, use the settings seen on the image to the right in the Page Handling area of the Adobe Reader print dialogue box. If your printer is cutting edges off, set "Page Scaling" to "Shrink to Printable Area". This will, however, decrease the size of the pattern a very small amount.



NOTE: Some patterns may reference tools, and other items no longer available.

NOTE: You may take this PDF file to your local print shop to have the full-size pages printed for your own personal use.

This premium has been published by Tandy Leather Factory, 1900 South East Loop 820, Ft. Worth, TX 76140. Copyright © 2011 by Tandy Leather Factory, all rights reserved. The contents of this publication may not be reproduced either in whole or in part without the consent of the copyright owner.

Please respect the copyright by not forwarding or distributing this document.