

Vintage Pattern Series

Stirrup Bag Pattern



This small size drawstring bag is easy to make.
The stirrup-shaped bag is designed to use a tooling leather strip on the outside edge and suede for the sides.
Pattern includes three tooling designs.
Finished size approx. 2-3/4"x6"x6-1/2".



LeathercraftLibrary.com
DIGITAL MEDIA FOR LEATHERCRAFTERS

Stirrup Bag Kit

STOCK NO. 4372

KIT CONTAINS:

Pre-Cut, Pre-Punched
Leather Parts
Leather Lace
and Needle
Grommets
Drawstrings

YOU WILL NEED:

Grommet Setter-
Stock No. 7052
Anvil-
Stock No. 1808



Distributed by Tandy Leather Co.
Fort Worth, Texas
A Division of Tandy Leather Co., Inc.

© Copyright 1989 by Tandy Leather Company, Fort Worth, TX 76101

KIT PARTS

A. GROMMETS

B. GUSSET

E. LEATHER LACE AND NEEDLE


C. SUEDE PANELS

D. DRAWSTRINGS

NOTE: DO ALL TOOLING, DYEING
AND FINISHING BEFORE ASSEMBLY.

STEP 1

FLESH SIDE



STEP 2

STEP 2: Set 6 grommets in 6 holes in one suede panel (C). Eyelet parts of grommets should be on front (good) side of panel. Repeat on other suede panel with 6 remaining grommets.



STEP 3

STEP 3: Line up diamond shaped hole in one end of gusset (B) over corner hole on left side of one suede panel (C), flesh (rough) side of gusset to back (rough) side of panel. Starting 4 holes down from diamond hole, double loop lace gusset to panel following double loop lacing instructions given on this sheet. Stop lacing when you reach second diamond shaped hole in gusset.




STEP 4

STEP 4: Line up second diamond shaped hole in gusset (B) over corner hole in left side of second suede panel (C), flesh (rough) side of gusset to back (rough) side of panel. Continue lacing around bag to starting point. Tie off lace as explained in double loop lacing instructions.

STEP 5

ILLUSTRATION A



DRAWSTRING

ILLUSTRATION B



STEP 5: Thread one drawstring (D) through grommets in gusset and panels (see illustration A). Tie ends of drawstring together in a knot (see illustration B). Thread second drawstring through same grommets from other side of gusset and tie drawstring ends in a knot as explained above.

Grommet Setting Instructions

LEATHER

FLESH
(ROUGH) SIDE

WASHER
EYELET

EYELET

SETTER - STOCK NO. 7052

ANVIL - STOCK NO. 1808

HOW TO LACE & SPLICE THE DOUBLE LOOP STITCH

- STEP 1. Beginning on front side of project, pull the needle and lace through the 1st hole. Leave about 3" of the lacing end and go on to lace the next hole.
- STEP 2. Pull the stitch tight, lacing over the end you left free. This forms a cross or "bight".
- STEP 3. Pull the stitch under the bight snug but not tight. Lace through the next hole.
- STEP 4. Follow the same procedure as in Steps 1 and 2 making a cross or bight. Once again go under the bight and pull the stitch snug.
- STEP 5. When lacing a corner, stitch through the three corner holes twice each. Be sure to go through bight on corner stitches.
- STEP 6. Lace until only 5" or 6" of lacing remain. You will now have to splice with a new length of lace.
- STEP 7. Insert new lacing down between leathers, 4 holes from lacing; pull out back side. Leave 3" of lacing between leather.
- STEP 8. Tuck end of lace between leathers and continue lacing your project with the old lace.
- STEP 9. Pull the old lace up tight, cut off the end at an angle, allowing about 1/2" to remain. Attach needle to new lacing.
- STEP 10. Tuck the end of the old lacing between the leathers and lace over it with the new lace so that it is caught and won't show.
- STEP 11. Continue lacing to starting point.
- STEP 12. To tie off lacing, pull end of beginning lace free of stitches.
- STEP 13. From back side pull the end of lace out of the hole.
- STEP 14. From front side, pull end of lace out of the loop.
- STEP 15. Push tool or needle down between leathers and hook it over the lace.
- STEP 16. Pull end of lace out of hole and up between leathers. Two empty holes should appear on the front side; one on the back.
- STEP 17. Cut off the end of the lace you have pulled out and tuck the end of the lace between the leathers. Lace through the next hole.
- STEP 18. Pull stitch tight and lace up through loop from the back side. All holes on the back side should be filled.
- STEP 19. Lace under the bight...do not pull this stitch tight.
- STEP 20. Carefully cross over as shown...and push needle down through the loop.
- STEP 21. Pull needle through. Push laced edges together to adjust starting loops for easier completion.
- STEP 22. Pull any slack out of the first loop and adjust lacing with fingers to make all your stitches appear equal.
- STEP 23. Pull the end of the lacing down tight. Make sure all stitches appear even and equally spaced.
- STEP 24. Push needle through the last hole as shown. Bring it up between the leathers and out between the lacing. Cut off the excess lace.

Stirrup Bag Kit

STOCK NO. 4372

KIT CONTAINS:

Pre-Cut, Pre-Punched
Leather Parts
Leather Lace
and Needle
Grommets
Drawstrings


YOU WILL NEED:

Grommet Setter-
Stock No. 7052
Anvil-
Stock No. 1808



Distributed by Tandy Leather Co.
Fort Worth, Texas
A Division of Tandy Crafts, Inc.


© Copyright 1989 by Tandy Leather Company, Fort Worth, TX 76101




STEP 2: Set 6 grommets in 6 holes in one suede panel (C). Eyelet parts of grommets should be on front (good) side of panel. Repeat on other suede panel with 6 remaining grommets.



STEP 3: Line up diamond shaped hole in one end of gusset (B) over corner hole on left side of one suede panel (C), flesh (rough) side of gusset to back (rough) side of panel. Starting 4 holes down from diamond hole, double loop lace gusset to panel following double loop lacing instructions given on this sheet. Stop lacing when you reach second diamond shaped hole in gusset.




NOTE: DO ALL TOOLING, DYEING AND FINISHING BEFORE ASSEMBLY.



STEP 1: Set 4 grommets (A) in 4 holes in gusset (B) following grommet setting instructions given on this sheet. Eyelet parts of grommets should be on grain (smooth) side of gusset.




STEP 4: Line up second diamond shaped hole in gusset (B) over corner hole in left side of second suede panel (C), flesh (rough) side of gusset to back (rough) side of panel. Continue lacing around bag to starting point. Tie off lace as explained in double loop lacing instructions.




STEP 5: Thread one drawstring (D) through grommets in gusset and panels (see illustration A). Tie ends of drawstring together in a knot (see illustration B). Thread second drawstring through same grommets from other side of gusset and tie drawstring ends in a knot as explained above.

Grommet Setting Instructions

LEATHER



FLESH
(ROUGH) SIDE




SETTER — STOCK NO. 7052



ANVIL — STOCK NO. 1808


HOW TO LACE & SPLICE THE DOUBLE LOOP STITCH

①




STEP 1. Beginning on front side of project, pull the needle and lace through the 1st hole. Leave about $\frac{1}{4}$ " of the lacing end and go on to lace the next hole.

②



STEP 2. Pull the stitch tight, lacing over the end you left free. This forms a cross or "bight".

③




STEP 3. Pull the stitch under the bight snug but not tight. Lace through the next hole.

④




STEP 4. Follow the same procedure as in Steps 1 and 2 making a cross or bight. Once again go under the bight and pull the stitch snug.

⑤




STEP 5. When lacing a corner, stitch through the three corner holes twice each. Be sure to go through bight on corner stitches.

⑥



STEP 6. Lace until only 5" or 6" of lacing remain. You will now have to splice with a new length of lace.

⑦



STEP 7. Insert new lacing down between leathers, 4 holes from lacing; pull out back side. Leave $\frac{1}{4}$ " of lacing between leather.

⑧



STEP 8. Tuck end of lace between leathers and continue lacing your project with the old lace.

⑨



STEP 9. Pull the old lace up tight, cut off the end at an angle, allowing about $\frac{1}{4}$ " to remain. Attach needle to new lacing.

⑩




STEP 10. Tuck the end of the old lacing between the leathers and lace over it with the new lace so that it is caught and won't show.

⑪



STEP 11. Continue lacing to starting point.

⑫



STEP 12. To tie off lacing, pull end of beginning lace free of stitches.

⑬



STEP 13. From back side pull the end of lace out of the hole.

⑭



STEP 14. From front side, pull end of lace out of the loop.

⑮




STEP 15. Push tool or needle down between leathers and hook it over the lace.

⑯



STEP 16. Pull end of lace out of hole and up between leathers. Two empty holes should appear on the front side; one on the back.

⑰



STEP 17. Cut off the end of the lace you have pulled out and tuck the end of the lace between the leathers. Lace through the next hole.

⑱



STEP 18. Pull stitch tight and lace up through loop from the back side. All holes on the back side should be filled.

⑲



STEP 19. Lace under the bight...do not pull this stitch tight.

⑳




STEP 20. Carefully cross over as shown, and push needle down through the loop.

㉑



STEP 21. Pull needle through. Push laced edges together to adjust starting loops for easier completion.

㉒



STEP 22. Pull any slack out of the first loop and adjust lacing with fingers to make all your stitches appear equal.

㉓



STEP 23. Pull the end of the lacing down tight. Make sure all stitches appear even and equally spaced.

㉔



STEP 24. Push needle through the last hole as shown. Bring it up between the leathers and out between the lacing. Cut off the excess lace.

Size 1 Mini Punch

Size 12 Maxi Punch




SUEDE PANEL:

If you are cutting from your own leather
Cut 2 Suede Panels from 2 to 4 oz. suede.




Size 12 Maxi Punch




Size 1 Mini Punch

Diamond Shaped Holes









GUSSET:
If you are cutting from
your own leather, cut
1 Gusset out of 6 to 7 oz.
tooling leather. Flop pattern
for complete Gusset.





SUEDE PANEL:
If you are cutting from your own leather
Cut 2 Suede Panels from 2 to 4 oz. suede.





GUSSET:



If you are cutting from
your own leather, cut
1 Gusset out of 6 to 7 oz.
tooling leather. Flop pattern
for complete Gusset.

Stirrup Bag Pattern

Visit www.tandy Leather Factory for all the supplies needed to complete this carving.
Visit www.LeadercraftLibrary.com for more great carving patterns.

©2012 Tandy Leather Factory. All rights reserved.


Artwork by George Hurst
All designs are reproduced at 100%
Page 1 of 2



Stirrup Bag Pattern


Visit www.tandyleatherfactory.com for all the supplies needed to complete this carving.
Visit www.LedhercraftLibrary.com for more great carving patterns.
©2012 Tandy Leather Factory. All rights reserved.

Artwork by George Hurst
All designs are reproduced at 100%
Page 2 of 2



Main Body Parts

Cut Two (2) from
4/5 oz. Chap Leather or Cowhide Suede




Stirrup Bag Pattern

Visit www.tandyleatherfactory.com for all the supplies needed to complete this carving.
Visit www.LeachercraftLibrary.com for more great carving patterns.


©2012 Tandy Leather Factory. All rights reserved.

Artwork by George Hurst
All designs are reproduced at 100%
Page 1 of 2





5/16" Holes




Join End to End
and Cut One (1) from
8/9 oz. Vegetable Tanned Cowhide

A

B

B





A


TLF_STIRRUP BAG WEB PATTERN_0612


Stirrup Bag Pattern


Visit www.tandyleatherfactory.com for all the supplies needed to complete this carving.
Visit www.LathercraftLibrary.com for more great carving patterns.

©2012 Tandy Leather Factory. All rights reserved.


Artwork by George Hurst
All designs are reproduced at 100%
Page 2 of 2







vo (2) from
her or Cowhide Suede



TLF_STIRRUP BAG WEB PATTERN_0612