



Digital Downloads

This PDF package has been put together to give you options when it comes to printing. Some PDF file downloads may contain some documents larger than an 8-1/2" x 11" image. Pages and patterns that are larger than 8%x11 have been provided in two formats:



Full Size: If you would like to have a full size print out, take the full size pages to your local print shop and they can print it for you.

Tiled: The tiled pages give you the option of printing the larger patterns at home. You print the tiled pages and then assemble them to make the larger patterns.



<u>Pattern PDF files</u> are typically laid out as follows: Cover (if applicable), instructions sheets (if applicable), pattern 1 – full sized, pattern 2 – full sized, pattern 2 – tiled, pattern 3 – full sized, pattern 3 – tiled. ...Etc.


<u>Doodle Page PDF files</u> are typically laid out as follows: Front – full sized, front – tiled, back – full sized, back – tiled (Some Doodle Pages do not have backs).

<u>eBook PDF files</u> contain 1 (one) full eBook. All pages in the PDF are full sized. This means that you may have to take the PDF to a print shop for certain oversized books if your home printer cannot print the larger pages.

<u>Craftaid PDF files</u> contain 1 (one) full Craftaid pattern or Craftaid pattern pack that has been converted into a tracing pattern. All pages in the PDF are full sized. This means that you may have to take the PDF to a print shop for certain oversized Craftaid patterns if your home printer cannot print the larger pages. *NOTE: These digitized patterns do not include any of the physical plastic templates (Craftaids) that may be mentioned, nor does the purchase of this PDF file imply a promise to receive any physical plastic templates (Craftaids).*

NOTE: Digital kit patterns do not include any kit parts that they may reference.

Please note: When printing on a home printer, use the settings seen on the image to the right in the Page Handling area of the Adobe Reader print dialogue box. If your printer is cutting edges off, set "Page Scaling" to "Shrink to Printable Area". This will, however, decrease the size of the pattern a very small amount.



NOTE: Some patterns may reference tools, and other items no longer available.

NOTE: You may take this PDF file to your local print shop to have the full-size pages printed for your own personal use.


This premium has been published by Tandy Leather Factory, 1900 South East Loop 820, Ft. Worth, TX 76140. Copyright © 2011 by Tandy Leather Factory, all rights reserved. The contents of this publication may not be reproduced either in whole or in part without the consent of the copyright owner.

Please respect the copyright by not forwarding or distributing this document.

www.leathercraftlibrary.com

Christmas Crafts from Tandy Leather





Candy Cane Ornament

You will need:

ill. A

%"x10" Strip of 4 oz. Tooling Leather Red and White Cova Colors #2041 Tacks and/or Nails

Sewing Thread Spool (1" to 11/4" diameter)

Step 1: Cut one %"x10" strip of tooling leather for each candy cane you want to make.


Step 2: Dye edges of strip with red Cova Color®.

Step 3: After dye has dried, dampen flesh (rough) side of strip thoroughly with water. Twist and pull until flesh side of strip is totally hidden (ill. A).

Step 4: Secure thread spool to wooden work surface with nail through the center hole. Tack one end of twisted cane to work surface. Bend cane around spool, then tack other end down (ill. B).

Step 5: Let candy cane dry completely, then cut ends loose from tacks (ill. B).

Step 6: Dye large spirals with white Cova Color or leave natural. Apply a finish like Satin Shene if spirals are to be left natural.



Diamond Shape Ornament

You will need:

4 to 5 oz. Tooling Leather
1½ yds. Solid Plastic Lace #3902 or
leather lace
Lacing Needle
Size 1 Mini Punch (½²") #1766
Large Wooden Bead #1472 (for style 1)
Round Drive Punch #2436 (for style 2 or 3)
½" Dance Bell #2988 (for style 2)
1½" Diameter Glass Ball Christmas
ornament (for style 3)


For all 3 styles: Cut 3 diamond shapes out of tooling leather using the cutting pattern at right. Mark, then punch lacing holes as shown on the cutting pattern.

For Style 1: Do all stamping, dyeing and finishing. Lace 3 diamond shapes together around wood bead following lacing instructions bélow (ill. A-D).


For Style 2: Punch 1" hole in center of 3 diamond shapes. Do all stamping, dyeing and finishing. Lace 3 diamond shapes together following lacing instructions below (ill. A-D). Tie one end of 6" long piece of lace to loop in dance bell. Push other end of

lace up through top of ornament from inside. Tie lace in a knot to secure, then trim off any excess.


For Style 3: Punch 1" hole in center of 3 diamond shapes. Do all stamping, dyeing and finishing. Lace 3 diamond shapes together around glass ornament following lacing instructions below (ill. A-D).









Step 1: Tie a knot in one end of a 1½ yd. piece of lace. Starting from the flesh (rough) side of leather, whipstitch lace up 2 edges "A" as shown (ill. A)



Step 2: Whipstitch lace down two edges "B" as shown (ill. B).



Step 3: Whipstitch lace up two edges "C" as shown (ill.C). After lacing through last hole, push end of lace up through area where top of three diamond shapes meet.



Step 4: Form a loop out of lace end and tie in a knot as shown (ill. D).

